

## LA-UR-21-21201

Approved for public release; distribution is unlimited.

Title:	Non-Destructive Assay and Measurement Control for Domestic Nuclear Safeguards
Author(s):	Greene, Wilder Robert
Intended for:	Slideshow for guest speaking at Montana State University Bozeman. Audience will be Analytical Chemistry students. Presentation supports discussion of non-destructive assay and measurement/process control.
Issued:	2021-02-09

---

**Disclaimer:**

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by Triad National Security, LLC for the National Nuclear Security Administration of U.S. Department of Energy under contract 89233218CNA000001. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

# Non-Destructive Assay and Measurement Control for Domestic Nuclear Safeguards

---

PRESENTED BY:

WILDER GREENE

# Talking points

---

- Education/Career Background
- What is Non-Destructive Assay?
- What is Measurement Control?
- Examples!

# Education/Career Background

---

- Graduated MSU in Fall of 2013 with a BS in Environmental Science (Soil & Water Science)
- Undergraduate Research Assistant under Dr. Klassen in the Environmental Analytical Laboratory
- Radiological Control Technician at the Department of the Navy
- Industrial Hygienist with the Army Corps of Engineers
- Measurement Specialist with Los Alamos National Laboratory

# What is Non-Destructive Assay?

---

# What is Non-Destructive Assay?

---

- Techniques to measure radiation induced (active) or emitted (passive) spontaneously from nuclear material

Non-Destructive= Does not alter physical/chemical state of material being measured.

# What is Non-Destructive Assay?

---

- Techniques to measure radiation induced (active) or emitted (passive) spontaneously from nuclear material

Non-Destructive= Does not alter physical/chemical state of material being measured.

## **Benefits:**

- Eliminates the need for sampling/expending material
- Often fast and inexpensive



# What is Non-Destructive Assay?

---

- Techniques to measure radiation induced (active) or emitted (passive) spontaneously from nuclear material

Non-Destructive= Does not alter physical/chemical state of material being measured.

## **Benefits:**

- Eliminates the need for sampling/expending material
- Often fast and inexpensive

## **Drawbacks:**

- Less accurate compared to destructive analysis

# Non-Destructive Assay Instruments

---

## Gamma Spectroscopy

Resolution can be Low (Sodium Iodide) or High (High-Purity Germanium)



<https://www.ortec-online.com/products/radiation-detectors/germanium-hpge-radiation-detectors>

# Non-Destructive Assay Instruments

---

## Gamma Spectroscopy

Resolution can be Low (Sodium Iodide) or High (High-Purity Germanium)

Item(s) are modeled to include:

- Effective matrix density (dimensions, weight)
- Matrix of material
- Distance from detector
- Primary/secondary wall thickness/material



<https://www.ortec-online.com/products/radiation-detectors/germanium-hpge-radiation-detectors>

# Non-Destructive Assay Instruments

---

## Gamma Spectroscopy

Resolution can be Low (Sodium Iodide) or High (High-Purity Germanium)

Item(s) are modeled to include:

- Effective matrix density (dimensions, weight)
- Matrix of material
- Distance from detector
- Primary/secondary wall thickness/material

These support the calculation that estimates total activity (curies).



<https://www.ortec-online.com/products/radiation-detectors/germanium-hpge-radiation-detectors>

# Non-Destructive Assay Instruments

---

## Gamma Spectroscopy

Resolution can be Low (Sodium Iodide) or High (High-Purity Germanium)

Item(s) are modeled to include:

- Effective matrix density (dimensions, weight)
- Matrix of material
- Distance from detector
- Primary/secondary wall thickness/material

These support the calculation that estimates total activity (curies).

Using specific activities, one can determine gram quantity



<https://www.ortec-online.com/products/radiation-detectors/germanium-hpge-radiation-detectors>

# Non-Destructive Assay Instruments

---

## Neutron

Can be active (interrogation) or passive measurements



<https://www.mirion.com/products/wm3210-passive-active-neutron-cf-252-shuffler-system>



<https://www.mirion.com/products/jcc-51-active-well-neutron-coincidence-counter>

# Non-Destructive Assay Instruments

---

## Neutron

Can be active (interrogation) or passive measurements

Active Measurements are used for isotopes that have a **low** spontaneous fission rate and require an external source (Cf-252, AmBe, etc.) to proliferate neutrons



<https://www.mirion.com/products/wm3210-passive-active-neutron-cf-252-shuffler-system>



<https://www.mirion.com/products/jcc-51-active-well-neutron-coincidence-counter>

# Non-Destructive Assay Instruments

---

## Neutron

Can be active (interrogation) or passive measurements

Active Measurements are used for isotopes that have a **low** spontaneous fission rate and require an external source (Cf-252, AmBe, etc.) to proliferate neutrons

Passive Measurements are used for isotopes that have a **high** spontaneous fission rate and require no external interrogation



<https://www.mirion.com/products/wm3210-passive-active-neutron-cf-252-shuffler-system>



<https://www.mirion.com/products/jcc-51-active-well-neutron-coincidence-counter>



# Non-Destructive Assay Instruments

---

## Neutron

Can be active (interrogation) or passive measurements

Active Measurements are used for isotopes that have a **low** spontaneous fission rate and require an external source (Cf-252, AmBe, etc.) to proliferate neutrons

Passive Measurements are used for isotopes that have a **high** spontaneous fission rate and require no external interrogation

Measurement systems outfitted with Helium-3 tubes incased in High-density poly-ethylene (neutron moderator)



<https://www.mirion.com/products/wm3210-passive-active-neutron-cf-252-shuffler-system>



<https://www.mirion.com/products/jcc-51-active-well-neutron-coincidence-counter>

# Non-Destructive Assay Instruments

---

## Neutron

Can be active (interrogation) or passive measurements

Active Measurements are used for isotopes that have a **low** spontaneous fission rate and require an external source (Cf-252, AmBe, etc.) to proliferate neutrons

Passive Measurements are used for isotopes that have a **high** spontaneous fission rate and require no external interrogation

Measurement systems outfitted with Helium-3 tubes incased in High-density poly-ethylene (neutron moderator)

Fission neutrons roll in pairs (or multiples)! Neutrons are time-correlated and used to quantify material



<https://www.mirion.com/products/wm3210-passive-active-neutron-cf-252-shuffler-system>



<https://www.mirion.com/products/jcc-51-active-well-neutron-coincidence-counter>

# Non-Destructive Assay Instruments

---

## Calorimetry

Calorimetric (heat) measurement to assert total heat output

- Calorimeter is a well within a water or air bath
- Heat output is calculated for item

# Non-Destructive Assay Instruments

---

## Calorimetry

Calorimetric (heat) measurement to assert total heat output

- Calorimeter is a well within a water or air bath
- Heat output is calculated for item

Isotopics are obtained using gamma spectroscopy (usually)

- Weight percent of isotopes are asserted for the item

# Non-Destructive Assay Instruments

---

## Calorimetry

Calorimetric (heat) measurement to assert total heat output

- Calorimeter is a well within a water or air bath
- Heat output is calculated for item

Isotopics are obtained using gamma spectroscopy (usually)

- Weight percent of isotopes are asserted for the item

Specific power is a *known*

# Non-Destructive Assay Instruments

---

## Calorimetry

Calorimetric (heat) measurement to assert total heat output

- Calorimeter is a well within a water or air bath
- Heat output is calculated for item

Isotopics are obtained using gamma spectroscopy (usually)

- Weight percent of isotopes are asserted for the item

Specific power is a *known*

Heat output (measured) + weight percent via isotopics (measured) + specific heat (known) = Quantity

# Measurement Control

---

Measurement control is to:

- Ensure instrument stability
- Minimize uncertainty
- Provide a pedigree for instrument performance

# Measurement Control

---

Measurement control is to:

- Ensure instrument stability
- Minimize uncertainty
- Provide a pedigree for instrument performance

Measurement control provides **current** data to support random and systematic uncertainties



# Measurement Control

---

Measurement control is to:

- Ensure instrument stability
- Minimize uncertainty
- Provide a pedigree for instrument performance

Measurement control provides **current** data to support random and systematic uncertainties

Instrument performance is validated using **traceable standards**.

# Measurement Control

---

Measurement control is to:

- Ensure instrument stability
- Minimize uncertainty
- Provide a pedigree for instrument performance

Measurement control provides **current** data to support random and systematic uncertainties

Instrument performance is validated using **traceable standards**.

Signals when there could be a problem with an instrument

- $2\sigma$  = Warning (95.45% of values found within this limit)
- $3\sigma$  = Alarm (99.73% of values found within this limit)

# Measurement Control

---

Measurement control is to:

- Ensure instrument stability
- Minimize uncertainty
- Provide a pedigree for instrument performance

Measurement control provides **current** data to support random and systematic uncertainties

Instrument performance is validated using **traceable standards**.

Signals when there could be a problem with an instrument

- $2\sigma$  = Warning (95.45% of values found within this limit)
- $3\sigma$  = Alarm (99.73% of values found within this limit)

Visualized with **Control Plot**

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Control Plot Example

In this case...

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Control Plot Example

In this case...

- The control plot will show the measured value with respect to the certified value (i.e. deviation from “*normal*”)

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Control Plot Example

In this case...

- The control plot will show the measured value with respect to the certified value (i.e. deviation from “*normal*”)
- Control plot values are expected to be centered around 1

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Control Plot Example

In this case...

- The control plot will show the measured value with respect to the certified value (i.e. deviation from “*normal*”)
- Control plot values are expected to be centered around 1
- Data is used to establish standard deviation ( $\sigma$ ) and bias

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Control Plot Example

In this case...

- The control plot will show the measured value with respect to the certified value (i.e. deviation from “*normal*”)
- Control plot values are expected to be centered around 1
- Data is used to establish standard deviation ( $\sigma$ ) and bias
- Useful in observing *as found* instrument behavior



#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Number of Data Points

Should have adequate amount of data to understand instrument behavior

Data should conform to the *central limit theorem*

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Standard ID & Value

Should have unique standard ID

*This standard is traceable and established through a superior method*

Used as the denominator for the Control Plot ratio

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Measured Value

Measured value (relatively self explanatory)

Used as the numerator in the Control Plot ratio

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952

# Measured/Certified (i.e. Control Plot Values)

Value is unitless (gram/gram, watt/watt, etc)

Shows relationship between the measured vs certified

- 1.1= measured value is higher than the reference value
- 0.9= measured value is lower than the reference value

#	Standard	Certified Value	Measured Value	Measured/Certified
1	A	25.0000	25.27	1.0108
2	A	25.0000	24.50	0.98
3	A	25.0000	25.24	1.0096
4	A	25.0000	24.76	0.9904
5	A	25.0000	24.00	0.96
6	A	25.0000	25.34	1.0136
7	A	25.0000	25.13	1.0052
8	A	25.0000	24.60	0.984
9	A	25.0000	24.88	0.9952
10	A	25.0000	24.76	0.9904
11	A	25.0000	25.02	1.0008
12	A	25.0000	24.84	0.9936
13	A	25.0000	25.41	1.0164
14	A	25.0000	24.75	0.99
15	A	25.0000	24.73	0.9892
16	A	25.0000	24.97	0.9988
17	A	25.0000	24.83	0.9932
18	A	25.0000	25.02	1.0008
19	A	25.0000	25.90	1.036
20	A	25.0000	24.80	0.992
21	A	25.0000	25.26	1.0104
22	A	25.0000	24.50	0.98
23	A	25.0000	25.17	1.0068
24	A	25.0000	24.51	0.9804
25	A	25.0000	25.16	1.0064
26	A	25.0000	24.90	0.996
27	A	25.0000	24.79	0.9916
28	A	25.0000	25.22	1.0088
29	A	25.0000	25.19	1.0076
30	A	25.0000	24.97	0.9988
31	A	25.0000	24.86	0.9944
32	A	25.0000	24.88	0.9952


Standard Deviation ( $\sigma$ )	0.013804534
Bias	0.9977

# Standard Deviation/Bias


Standard Deviation is basis of control limits

Bias indicates if reality of instrument needs to be adjusted


# Control Plot (Measured/Certified)



# Control Plot (Measured/Certified)




# Control Plot (Measured/Certified)






# Control Plot (Measured/Certified)



# Control Plot (Measured/Certified)



This is expected!!!

---

# This is expected!!!

---

Some points outside of 2 sigma are expected in a normal data set (**about 5%**)

# This is expected!!!

---

Some points outside of 2 sigma are expected in a normal data set (**about 5%**)

Even the occasional random 3 sigma failure (**<1%**) is expected to occur over the lifetime of the instrument

# This is expected!!!

---

Some points outside of 2 sigma are expected in a normal data set (**about 5%**)

Even the occasional random 3 sigma failure (<**1%**) is expected to occur over the lifetime of the instrument

This would be considered an issue when back-to-back or 2 out of 3 points outside of  $2\sigma$

# Other considerations...

---

Points outside of  $3\sigma$  or  $2\sigma$  are not the only signal for anomalous data

# Other considerations...

---

Points outside of  $3\sigma$  or  $2\sigma$  are **not the only signal** for anomalous data

Process control metrics can indicate other problematic features of a data set



# Other considerations...

---

Points outside of  $3\sigma$  or  $2\sigma$  are **not the only signal** for anomalous data

Process control metrics can indicate other problematic features of a data set

Examples of these metrics are:

**Western Electric**

**Nelson**

# Other considerations...

---

Points outside of  $3\sigma$  or  $2\sigma$  are **not the only signal** for anomalous data


Process control metrics can indicate other problematic features of a data set

Examples of these metrics are:


**Western Electric**

**Nelson**

# Common Rules and what they imply!




# Common Rules and what they imply!




- Single Point outside of  $3\sigma$


# Common Rules and what they imply!



# Common Rules and what they imply!




# Common Rules and what they imply!



- 2 out of 3 consecutive points outside of  $2\sigma$


# Common Rules and what they imply!



- 2 out of 3 consecutive points outside of  $2\sigma$
- Data showing higher frequency being outside of expected confidence intervals




# Common Rules and what they imply!



- 9 consecutive data points below/above the mean
- May indicate a prolonged bias

# General Data Awareness



# How it relates to Safeguards

---

Values obtained from measurement systems are used to account for nuclear materials!

We must ensure these systems perform within an expected range

Having a high confidence in instrument performance is equal to high confidence material present





# Questions?

---

Wilder Greene

[wilder.greene@gmail.com](mailto:wilder.greene@gmail.com)

## Nondestructive Assay Resource

PANDA Manual- Fantastic resource for non-destructive assay

<https://www.lanl.gov/org/ddste/aldgs/sst-training/Panda%20Manual%20Chapters.php>